



Il regolatore di livello con galleggiante è destinato all'utilizzo in serbatoi a pressione atmosferica. La spinta idrostatica generata dal liquido sul galleggiante provoca il movimento di apertura o chiusura grazie al meccanismo a leva.

**Avvertenza per la sicurezza:**

Non sono destinati ad utilizzi di sicurezza su recipienti in pressione nelle categorie "CI - CII - CIII - CIV".

Non sono idonei a contenere fluidi del gruppo 1 / 2 allo stato gas/vapore o liquido con tensione di vapore superiore di 0,5 bar rispetto alla pressione atmosferica (1013 mbar) alla massima temperatura di esercizio prevista (direttiva PED 97/23/CEE).

**Manutenzione:**

- Prima di procedere ad eventuali manutenzioni,effettuare la completa evacuazione del fluido contenuto ed accertarsi che non sia più sotto pressione.
- Utilizzare idonei dispositivi di protezione individuale in funzione delle guarnizioni ed eventualmente dello stelo otturatore se danneggiati.

**Attenzione!!**

- Per prevenire il pericolo di allagamenti in caso di guasto del rubinetto, dotare obbligatoriamente la vasca o cassetta di accumulo di scarico di sicurezza ("troppo pieno") dimensionato con n maggiore rispetto a quello del tubo di alimentazione.

**Installazione ed uso:**

- Installare senza esercitare forze e torsioni sul meccanismo.
- Utilizzare idonei elementi di tenuta sulle connessioni filettate.
- verificare sempre la compatibilità dei materiali con i fluidi e rispettare i limiti d'uso previsti (pressione e temperatura).

**Pressione massima di esercizio consigliata: 5bar**

**Temperatura massima dell'acqua consigliata: 60°C**

*The floating level regulator is intended for atmospheric pressure tanks. The hydrostatic thrust generated by the liquid on the float causes it to open or close thanks to the lever mechanisms.*

**Safety warning:**

Should not be used for safety purposes with pressurized containers in "CI - CII - CIII - CIV" categories.

They are not suitable for containing fluids in groups 1 / 2 in gas/steam or liquids with vapor pressure higher than 0.5 bars as compared with the atmospheric pressure (1013 mmbar) and a maximum expected operating temperature (PED 97/23/CEE Directive).

**Installation and use:**

- Install without using force and bending/contorting the mechanics.
- Use suitable sealing elements on the threaded connections.
- be sure to check the compatibility of the materials with the fluids and respect the limits of use (pressure and temperature).

**Maintenance:**

- Before proceeding with any maintenance, completely get rid of the fluid contained and make sure it is no longer under pressure.
- Use suitable individual protective equipment according to the gaskets and, if necessary, the disc stem if damaged.

**Warning!!!**

- In the event of a faulty tap and in order to prevent the risk of flooding, you must use a tank or an overflow drainage accumulation tank. ("overflow") sized with a diameter (Ø) larger than the supply pipe.

**Maximum recommended working pressure: 5bar**

**Maximum recommended working temperature: 60°C**

**Sfere consigliate**

**Recommended size balls**

	3/8"	1/2"
GA0212FI	90	90
GA0222FI	90	90
GA0202FI	90	
GA0203FI		100

**Dimensioni / Dimensions.**

ART.	Sede / Seat	A	B	c	D	E	F	G
GA004CSA	Ottone / Brass	3/8"	30	70	160	35	1/4W	240
GA004DSA	Ottone / Brass	1/2"	30	70	185	35	1/4W	260
GA005CSA	Inox / Stainless steel	3/8"	30	70	160	35	1/4W	240
GA005DSA	Inox / Stainless steel	1/2"	30	70	185	35	1/4W	260

**COMPONENTI / COMPONENTS**

Corpo / Body	Ottone / Brass: CB753S
Coppiglie / Cotter-pins	Ottone / Brass: CW508L
Componenti in ottone / Brass components	Ottone / Brass: CW614N
Guarnizioni / Seals	NBR - SBR
Sede / Seat	Ottone / Brass: CW614N – Acciaio inox / Stainless steel AISI304

Scheda tecnica Art.

**GA004CSA-GA005CSA**

REV.00 14/03/2023